




Welcome to your new home and your Wiser Heating controls for your central heating system. Your heating is already set up and ready to use from the day you move in.

- If you find it too warm or cold, you can turn the temperature up and down using the plus and minus buttons on your room thermostat.
- If you have two zones in your house, you have two room thermostats to individually alter the temperature upstairs and downstairs.
- The times and temperature for your heating have already been set up to follow the schedule below.

Monday - Friday		Saturday - Sunday	
Time	Temp	Time	Temp
6:30 am	20.0°C	7:00 am	20.0°C
8:30 am	16.0°C	9:00 am	18.0°C
4:30 pm	21.0°C	4:00 pm	21.0°C
10:30 pm	Off*	11:00 pm	Off*

Pre-programmed schedule. *Only frost protection is active.



If you wish to alter this pre-set schedule, then please download the Wiser Home app on your smartphone and follow the instructions below.



NO BROADBAND YET? NO PROBLEM

If you need to change your heating schedule, make sure you have the Wiser Home app downloaded on your phone and follow these steps below for a temporary in-home connection to the Wiser system.




Step 1

Open the Wiser Home app and click 'Get Started'.



Step 2

Choose Hub^R.




Step 3

On your Hub^R press Set Up once.



Step 4

Click Open Wi-Fi settings. Continued overleaf.




Step 5

Navigate to phone Wi-Fi settings.



Step 6

Look for Wiser Wi-Fi connection.



Step 7

Tap to select Wiser Wi-Fi connection.



Step 8

Return to Wiser Home app.



Step 9

Press Continue.



Step 10

Press Next.




Step 11

Press Skip.



Step 12

Press Skip.




Step 13

Press the room you want to alter the schedule for.



Step 14

Press Edit Schedule.



Step 15

Amend schedule to your chosen times/temps.



Finally

Make sure you log out and press Set Up on your hub again to stop it flashing.